

FENDT

Werkstatthandbuch

Workshopmanual

Manuel d'atelier

Manual de taller

Manuale per l'officina

Werkplaatshandboek

FENDT 900 Vario COM III

X 990.005.057.012

1

FENDT

Workshop Service Manual

FENDT 900 Vario - COM III

919 .. 0101-1000

919 .. 1001-

922 .. 0101-1000

922 .. 1001-

925 .. 0101-1000

925 .. 1001-

928 .. 0101-1000

928 .. 1001-

931 .. 0101-1000

931 .. 1001-

934 .. 0101-1000

934 .. 1001-



AGCO GmbH - Johann-Georg-Fendt-Str. 4 D-87616 Marktberndorf
FENDT is a worldwide brand of AGCO

Edition 02/2010
No. X990.005.057.012
3510 G - en
FENDT 900 Vario COM III - EAME
English

All relevant accident prevention regulations and all generally accepted safety, health and road traffic regulations must be strictly observed. The manufacturer does not accept liability for damage resulting from unauthorised modifications.

Changes and additions reserved!

A	General
B	Faults
C	Documents and Diagrams
D	Component location
E	Testing
F	Setting and Calibration
G	Repair
H	Service – Info

0000

Overall system/tractor

Overall system/tractor 0000

FENDT 900 Vario - COM III

Volume 1

0000	Overall system/tractor
1005	Overall system/transmission
1010	Transmission/differential
1015	Transmission/axle drive
1050	Transmission/housing
1070	Transmission / Brake system
1080	Transmission/drive train
1200	Transmission/front PTO
1220	Transmission / Live PTO
1320	Transmission/front wheel drive
2000	Overall system/engine
2010	Engine/cylinder head
2050	Engine/cooling
2060	Engine/fuel system
2210	Engine/crankcase
2312	Engine/lubrication
2400	Engine/exhaust system
2712	Engine/injectors
3000	Overall system/front axle
3120	Front axle/steering cylinder
3180	Front axle/cardan shaft

Volume 2

4000	Overall system/steering
4090	Steering system / hydraulic steering unit
5030	Vehicle layout/operator's seat
5500	Overall system/air conditioning system
8100	Overall system/cab
8610	Power lift/EPC electro-hydraulic control
8631	Power lift/hydraulic lift
8800	Overall system/compressed air system

Volume 3

9000	Overall system/electrical system
9015	Electrical system/starter lockout

FENDT 900 Vario - COM III

Volume 4

- 9410 Hydraulic pump installation/LS pump**
- 9430 Hydraulic pump installation/steering pump**
- 9534 Hydraulic piping/"Rüfa"reverse operation**
- 9600 Overall system/hydraulic equipment**
- 9605 Hydraulic equipment/hydraulic connections**
- 9610 Hydraulic equipment/central control block (ZSB)**
- 9620 Hydraulic equipment/valve fitting**
- 9700 Overall system/electronics**
- 9920 Service/special tools**
- 9975 Service/SERDIA - Deutz engine diagnostics program**

0000 Overall system/tractor

A	General.	5
B	Faults	39
D	Component position	123
F	Setting and calibrating	227

A General

1	Component overview	7
2	Documentation layout	11
3	Notes on documentation	12
4	Safety briefing and measures.	13
5	Biodiesel.	16
6	Biodegradable hydraulic oil.	17
7	Tightening torques for bolts in Nm (kpm).	18
8	History of the FENDT 900 VARIO (COM III) farm tractor.	19
9	Position of sign plates	29
10	Tractor diagnostics with terminal	33

1 Component overview

0000	Tractor – overall system

1000	Transmission
1005	Transmission control system
1010	Differential gear
1015	Axle drive
1030	Hand brake
1050	Housing
1070	Brake system
1080	Drive train
1090	Emergency actuation
1100	Clutch actuation
1150	Cardan brake
1170	ML range control
1200	Front PTO
1220	Live PTO
1320	Front wheel drive
1430	Hydrodamp
1432	Hydraulic pump
1470	Transmission lubrication
1490	Pump drive
1530	ML adjustment
1600	Enhanced control actuation valves
1620	Enhanced control actuation pipes

2000	Engine
2010	Cylinder head
2020	Speed setting
2050	Cooling system
2060	Fuel system
2170	Engine brake
2180	Cold-start system
2190	Intercooler
2210	Crankcase
2250	Engine preheater
2312	Lubrication
2710	Injection pump
2712	Injector valves
2714	Governor

3000	Front axle
3010	Front axle chock
3020	Axle body
3050	Suspension

3000	Front axle
3060	Suspension valve installation
3070	Suspension piping
3100	Track rod
3120	Steering cylinder
3170	Frame
3180	Cardan shaft
3190	Differential lock actuation

4000	Steering
4070	Steering wheel
4090	Hydraulic steering unit

5000	Vehicle layout
5010	Layout
5030	Driver seat
5050	Towing device
5161	Towing hitch
5200	Cab bearing, suspension

5500	Air conditioning system
5520	Compressor drive
5530	Coolant piping
5550	Evaporator
5560	Condenser
5570	Electrical wiring

8100	Cab
8113	Heater
8114	Ventilation
8117	Windscreen wipers
8121	Cable loom

8600	Power lift
8610	Electro-hydraulic EPC control
8618	External control
8631	Power lift control

8700	Three point linkage
8730	Lifting struts
8740	Support

8800	Compressed air system
8810	Air compressor
8820	Brake fittings
8830	Cables
8850	Electric actuation
8890	Air vessel

8900	Front loader
8910	Mounting frame
8915	Hydraulic equipment actuation
8955	3. Hydraulic circuit
8958	Multi coupling
5970	Piping
8990	Lift cylinder

9000	Electrical system
9010	Alternator
9015	Starter lock
9040	Fuses
9050	Battery installation
9060	Starter system

9200	Front power lift
9210	Linkage
9211	External control
9220	Cylinder
9230	Piping
9260	Enhanced power lift control
9280	Frame

9400	Hydraulic pump installation
9410	LS pump
9420	Transmission pump
9430	Steering pump

9500	Hydraulic piping
9510	Basic circuit
9516	Power lift
9525	With oil cooler
9530	Hydraulic trailer brake
9531	Steering
9534	Reverse operation

9600	Hydraulic equipment
9605	Hydraulic connections
9610	Central control block (ZSB)
9620	Valve installation
9666	External pressure supply
9690	Auxiliary valves

9700	Electronics
9710	Instrument panel
9715	Terminal
9717	LBS – agricultural bus system
9720	Sensor
9730	Radar sensor
9740	E-box
9750	Transmission actuator unit
9760	Driving switch
9770	Control panel
9780	Engine EDC
9790	Linkage ECU

9900	Service
9920	Special tools
9970	FENDIAS

2 Documentation layout

In this technical documentation, the different tractor types are basically divided according to components that, with a few technical exceptions, reflect the structure of replacement parts.

For example, these components may be "0000 – overall system"; "1005 – transmission control system"; "2000 – engine" etc.

see §1

Each component is divided into separate registers, identified by a register letter.

These are:

- A General
- B Faults
- C Documents and diagrams
- D Component position
- E Measuring and testing
- F Setting and calibrating
- G Repair
- H Service information

The content of this documentation consists of several individual documents in their own right. These documents can be used for a variety of technical documentation and are not type-specific.

Header and footer layout:

Header:

The header shows the group title, the document title and the register letter.

Footer:

Each document is specifically identified and has a version status and a release date that are shown at the bottom right (A) of the footer.

The applicability of each document according to chassis number range is shown at the bottom (B) of the footer.

NOTE: If the document does not apply to all chassis numbers, this is indicated by the additional information

"Refer to chassis number range"

(C).

FENDT 9000 Vario COM III		Allgemeines						
Anziehdrehmomente für Schrauben in Nm (kpm)		A						
<p>Reibwert: μ ges. 0,14 für Schrauben (und Mutter) ohne Nachbehandlung, sowie phosphatisierte Muttern. sowie phosphatisierte Muttern. Anziehen von Hand. Anziehdrehmomente, wenn nicht besonders angegeben, können auf folgender Aufstellung entnommen werden.</p>								
Metrisches Gewinde								
Abmessung	8,9		8,8		10,9		12,9	
	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)
M 5	8,4	(0,85)	9,8	(1,0)	13,2	(1,4)	16,7	(1,7)
M 6	20,6	(2,1)	24,5	(2,5)	34,3	(3,5)	40,2	(4,1)
M 10	40,2	(4,1)	48,1	(4,9)	67,7	(6,9)	81,4	(8,3)
M 12	70,6	(7,2)	84,4	(8,6)	117,7	(12,0)	142,2	(14,5)
M 14	112,8	(11,5)	132,4	(13,5)	186,4	(19,0)	225,6	(23,0)
M 16	176,6	(18,0)	206,0	(21,0)	289,4	(29,5)	348,2	(35,5)
M 18	240,3	(24,5)	284,5	(29,0)	392,4	(40,0)	475,8	(48,5)
M 20	338,4	(34,5)	402,2	(41,0)	569,0	(58,0)	678,9	(69,0)
M 22	456,2	(46,5)	539,9	(55,0)	765,2	(78,0)	912,3	(93,0)
M 24	588,6	(60,0)	696,5	(71,0)	981,0	(100,0)	1177,2	(120,0)
M 27	873,1	(89,0)	1030,0	(105,0)	1471,5	(150,0)	1755,8	(180,0)
M 30	1177,2	(120,0)	1422,4	(145,0)	1962,0	(200,0)	2354,4	(240,0)
Metrisches Feingewinde								
Abmessung	8,9		8,8		10,9		12,9	
	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)
M 8 x 1	22,8	(2,3)	26,5	(2,7)	37,3	(3,8)	44,1	(4,5)
M 10 x 1,25	42,3	(4,4)	51,8	(5,2)	71,6	(7,3)	86,3	(8,8)
M 12 x 1,25	78,5	(8,0)	93,2	(9,5)	132,4	(13,5)	157,0	(16,0)
M 12 x 1,5	14,5	(1,5)	17,2	(1,8)	24,2	(2,5)	29,0	(3,0)
M 14 x 1,5	123,6	(12,5)	147,1	(15,0)	206,0	(21,0)	245,2	(25,0)
M 16 x 1,5	186,4	(19,0)	220,7	(22,5)	309,0	(31,5)	372,8	(38,0)
M 18 x 1,5	259,8	(27,0)	318,8	(32,5)	451,3	(46,0)	539,5	(55,0)
M 20 x 1,5	377,7	(38,5)	451,3	(46,0)	627,8	(64,0)	755,4	(77,0)
M 22 x 1,5	510,1	(52,0)	598,4	(61,0)	843,7	(86,0)	1010,0	(103,0)
M 24 x 2	837,6	(85,0)	995,2	(102,0)	1391,1	(142,0)	1662,3	(170,0)
M 27 x 2	951,8	(97,0)	1128,1	(115,0)	1566,6	(160,0)	1912,9	(195,0)
M 30 x 2	1244,4	(127,0)	1499,6	(154,0)	2107,2	(215,0)	2550,0	(260,0)

Fig. 1

1003732

Check Chassis Range!

Fahrzeugsnummerbereich beachten!

3 Notes on documentation

To ensure that the information is structured in a user-friendly manner, the service documentation is divided into the operator's manual and the workshop manual.

The operator's manual includes a general description as well as instructions for all necessary maintenance work.

Knowledge of the owner's manual is essential to understand the workshop manual. This is particularly important for safety instructions.

The workshop manual describes repairs to the engine and components, which will require more effort and suitably qualified specialists to carry out.

Note

This workshop manual provides notes for trained technicians to maintain our tractors.

Read and observe the information in this documentation. This will help you prevent accidents and safeguard the manufacturer's warranty.

The respective accident prevention rules as well as other generally recognised safety and occupational health rules must be observed.

The tractor is built solely for the purpose defined by the implement manufacturer (intended use). Any other type of use is considered unauthorised. The manufacturer bears no liability for any damage resulting from improper use. The user bears this risk alone. Intended use includes maintaining operating, service and maintenance conditions as specified by the manufacturer.

The tractor may only be used, serviced and maintained by people familiar with the equipment and who have been informed about the dangers. Ensure that this documentation is available to everyone involved in operating, servicing and maintaining the tractor and that the contents have been understood. Not observing this documentation can lead to faults, engine damage and personal injury, for which the manufacturer assumes no liability. The prerequisite for the tractor being correctly serviced and maintained is the perfect condition and availability of all necessary equipment, standard tools and general workshop equipment as well as special tools. The use of special tools is restricted to where absolutely necessary, and are displayed both where they need to be used and in a summary at the end of the manual.

The tractor must be maintained according to its proper use. **Always** replace parts with genuine FENDT spare parts! When ordering parts, please provide the chassis number as per the most up-to-date spare parts documentation. The layout of components in this workshop manual matches **Epsilon**.

Only parts approved by the manufacturer for that specific purpose may be used for any alterations. The manufacturer will not accept liability for any damage resulting from unauthorised modifications to the tractor. Non-compliance invalidates the warranty!

Workshops should also refer to documentation on maintenance work and technical data.

Once maintenance is complete, take a test drive to ensure the vehicle's correct operation and road safety.

We reserve the right to make design changes in light of technical developments.

Notes on Register G - Maintenance

The assembly/disassembly instructions shown correspond to the design status at the time the workshop manual was drawn up.

Further technical development of the product and additions related to different versions may require alternative working processes that do not pose too many difficulties to trained and qualified specialists.

These assembly/disassembly instructions shall be invalidated upon issue of the next version of this document.

4 Safety briefing and measures

Important notes on work safety

The statutory accident prevention regulations (available from professional associations or specialist shops) must be observed. These depend on the operating site, operating mode and fuels and lubricants used. Special protective measures dependent on the respective procedures are specified in the corresponding repair guidelines and highlighted.

This handbook uses the following safety tips



DANGER: Indicates an impending dangerous situation that will lead to serious injury or death if not avoided.



WARNING: Indicates a potentially dangerous situation that could lead to serious injury or death if not avoided.



CAUTION: Indicates a potentially dangerous situation that could lead to minor injury if not avoided.

Please observe the following when carrying out maintenance or service work to the tractor:

Only the documentation associated with the vehicle (workshop manual and operator's manual) must be used to complete any pending work.

1. General

- Only briefed personnel may operate the tractor or carry out maintenance work.
- Only use qualified specialists to carry out repairs or service work.
- Nobody may be in the cab while work is being carried out under the jacked-up tractor.
- Relieve pressure from implement lines, e.g. front loader.
- Keep clear of any suspended, unsecured load (lifted cab etc.).
- Never open or remove any safety devices while the engine is running.
- Pressurised fluids (fuel or hydraulic oil) escaping under high pressure can penetrate the skin and cause severe injuries. If this should occur, seek medical advice immediately to avoid the risk of serious infection.
- Keep at a safe distance from hot areas.
- Pressure accumulator and connected lines are highly pressurised. Only remove and repair in accordance with instructions set out in the workshop manual.
- To avoid eye injury, do not look directly at the surface of the activated radar sensor.
- Dispose of oil, fuel and filters properly.
- Specialist knowledge and special fitting tools are required to fit tyres
- Run the tractor for a short time, then retighten all wheel nuts and bolts and check them regularly. For correct torque values refer to TECHNICAL DATA.
- Before working on the electrical system, always remove the earth strap from the battery. Observe the following when carrying out electric welding. Before carrying out welding work on tractor or mounted implements, ensure that both battery terminals are disconnected. Attach the earth terminal of the welding appliance as close to the welding spot as possible.
- Caution is required when dealing with brake fluid and battery acid as these are toxic and corrosive!
- Only use genuine FENDT spare parts.

2. Working on the front axle suspension

**DANGER:**

- The front axle suspension pressure lines between the central control block (ZSB) and the suspension cylinders, and
- the pressure accumulator on central control block ASP1 and
- the piped pressure accumulator ZSP

are under 200 bar pressure, even when the engine is switched off and the suspension is lowered (= locked).

Safety measures:

Prior to each repair and after releasing or opening in this area, the pressure must be released manually.

NOTE: The "Lock suspension/lower suspension" command has no effect!

Even externally energising the solenoid valves **Y013** - Suspension load pressure/lowering solenoid valve and **Y014** -

Raise suspension solenoid valve is not effective!

(Hydraulically unlockable non-return valves are fitted, RVFH raise suspension non-return valve/RVFS lower suspension non-return valve).

To release pressure:

- **AVF1** - Lock valve, suspension 1 open to left, chassis may lower
- **AVF2** - Lock valve, suspension 2 open to left, rebound accumulator will be relieved




Fig. 2.

EK106725
1005112

Check:

As the oil temperature rises, the emptying accumulator will make a flowing sound (barely audible in winter).

3. Working on the engine

- After switching off the engine, wait 30 seconds before carrying out any work on the fuel system.
- Only start the engine once all safety guards have been attached and nobody is standing in the danger area.
- Never let the engine run in enclosed spaces with no exhaust gas suction system.
- Cleaning, maintenance and repair work may only be carried out once the engine is switched off and secured to prevent it starting.
- Injection lines and high-pressure lines must not be deformed.
- Any damaged injection line or high-pressure line must be replaced.
- Do not loosen any injection lines for high-pressure fuel lines while the engine is running.
- Before carrying out checks to the running engine, always perform a visual check of all high-pressure components. Suitable protective clothing (e.g. protective goggles) should be worn while doing this. Leaks indicate potential sources of danger for workshop personnel.
- In the event of leaks to the high-pressure fuel system, always remain out of range of any possible fuel spray to avoid serious injury.
- Even when no leaks to the high-pressure fuel system can be detected, workshop personnel should avoid the immediate danger area and wear suitable protective clothing (such as protective goggles) when carrying out checks to the running engine and during the first test run.
- Smoking is forbidden while carrying out work to the fuel system.
- Do not work in the proximity of sparks or naked flames.
- Never disconnect an injector while the engine is running.

4. Working on the PTO

- Always switch off the engine before fitting or removing the drive shaft. PTO in "0" position!
- When working on the PTO, allow no one in the vicinity of the rotating PTO or drive shaft.
- Ensure the drive shaft shield pipe and protective funnel and the PTO guard are fitted.
- After deactivating the PTO, it is possible that parts on the mounted implement may continue to run as a result of the centrifugal mass. Whilst this continues, do not get too close to the implement. Work may only be carried out when the moving parts of the mounted implement have come to rest.
- When the drive shaft is removed, cover the PTO with its protective cap.
- Nobody should be in the cab when installing and removing the drive shaft.
Operation of controls for the tractor and mounted implements by people in the cab, especially children, may result in severe or fatal injury.

5. Working on the front loader

- Before undertaking maintenance work, lower the front loader to the ground, switch off the engine and remove the ignition key.
- If the pipe rupture safety feature activates, support the load before starting repair work, and slowly retract the cylinder.
- Carry out a regular check of hydraulic hoses and lines for signs of damage and aging and replace with genuine spare parts in good time.
- Following installation and repairs, operate the tractor for a short time, then retighten all nuts and bolts and check them regularly.
- Retighten eccentric bolt for front loader attachment, if necessary.

6. Working on the brake system

- Always check the brakes before driving.
- Adjustments and repairs to the brake system must be carried out in specialist workshops or by approved brake repair technicians.
- It must not be possible to brake individual wheels when driving (lock pedals)!
- Check the level of brake fluid at regular intervals. Only use the brake fluid specified and replace according to instructions!

Disposal

The work described in the operator's manual and workshop manual includes replacing parts, fuel and lubricants. These renewed parts/fuel/lubricants must be stored, transported and disposed of in accordance with regulations. The repairing workshop bears responsibility for this. The disposal encompasses the recycling and final disposal of parts/fuel/lubricants with recycling having the higher priority. Details about disposal and monitoring are specified in regional, national and international laws and directives, the observation of which is the sole responsibility of the repairing workshops.

5 Biodiesel

Fuel quality

RME=Rapeseed oil Methyl Ester,

VME=Vegetable oil Methyl Ester fuel

Use in accordance with DIN EN 14214.

Cold-pressed rapeseed oil is **not** approved for use with standard tractors.

Only cold-pressed fuel in accordance with DIN V 51605 is approved for Greentec tractors.

The following notes apply to the use of RME and VME

Instructions for use

Biodiesel is suitable for winter temperatures down to approx. -10 °C.

At temperatures below -10 °C, diesel fuel needs to be added to prevent flocculation of the biodiesel. The ratio of the two must be approx. 50:50. Diesel fuel must be used at temperatures below -16 °C.

Biodiesel can be mixed in any proportion with diesel fuel.

Engine performance is reduced by 10–15%.

There is a slight change in fuel consumption.

If the tractor is not going to be used for some time (3 months or more), fill with diesel fuel to prevent the injection components from seizing.

Maintenance intervals

Oil and oil filter change intervals must be halved.

If conventional diesel fuel has been used in the past, the fuel filter must be replaced after fuelling with biodiesel a few times. Since biodiesel acts as a solvent, any diesel residue may block the fuel filter.

Special features of biodiesel

Biodiesel is obtained from vegetable oil (mainly rapeseed oil) by means of a chemical process, where the vegetable oil is mixed with methanol and converted to biodiesel using a catalyst.

Biodiesel is virtually sulphur-free and therefore produces almost no sulphur dioxide during combustion.

The exhaust gas contains reduced levels of

than when using conventional diesel fuel. Biodiesel is more easily biodegradable and has less of an effect on the ground and groundwater in the event of accidental spills.

IMPORTANT: *In spite of the high environmental compatibility of biodiesel, accidental spills must always be reported.*

6 Biodegradable hydraulic oil

Oil quality

Use rapeseed-oil and synthetic-based HEES biodegradable hydraulic oil with a viscosity in accordance with ISO VG 32-ISO VG 46.

NOTE: *Polyglycol-based synthetic oils cannot be used.*

Instructions for use

Biodegradable hydraulic oil is suitable for winter temperatures down to approx. -15 °C.

Vegetable-based hydraulic oil may thicken in outside temperatures below approx. -15 °C or if the tractor is not used for long periods of time. After a cold start, allow a short warm-up time at medium engine speed to ensure safe operation of the hydraulic steering and linkage. In extremely low temperatures, it may be necessary to warm up the entire tractor.

Avoid mixing with mineral oils, e.g. with any oil remaining in the system or by connecting and operating an external implement. This may affect the positive environmental properties of the fluid, and will make it more difficult to dispose of (it will then have to be considered as special waste).

Current legislation and the instructions of the oil manufacturer must be observed when disposing of oil.

A mixture containing more than 20% may result in alterations in viscosity and may lead to problems with the hydraulic valves.

Maintenance intervals

The oil and oil filter need to be changed every 1000 running hours or every year, whichever occurs first.

When switching to biodegradable hydraulic oil, change the hydraulic oil filter after approx. 50–100 running hours. Since biodegradable hydraulic oil acts as a solvent, any oil residue may block the filter.

Special features of biodegradable hydraulic oil

Biodegradable hydraulic oil is more easily biodegradable and has less of an effect on the ground and groundwater in the event of accidental spills.

IMPORTANT: *In spite of the high environmental compatibility of biodegradable hydraulic oil, accidental spills must always be reported.*

7 Tightening torques for bolts in Nm (kpm)

Friction value: μ total 0.14 for screws and nuts without after-treatment and phosphated nuts. Tighten by hand.

When tightening torques are not specified, they can be found in the following diagram.

Metrisches Gewinde								
Abmessung	6,9		8,8		10,9		12,9	
	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)
M 6	8,4	(0,85)	9,8	(1,0)	13,7	(1,4)	16,7	(1,7)
M 8	20,6	(2,1)	24,5	(2,5)	34,3	(3,5)	40,2	(4,1)
M 10	40,2	(4,1)	48,1	(4,9)	67,7	(6,9)	81,4	(8,3)
M 12	70,6	(7,2)	84,4	(8,6)	117,7	(12,0)	142,2	(14,5)
M 14	112,8	(11,5)	132,4	(13,5)	186,4	(19,0)	225,6	(23,0)
M 16	176,6	(18,0)	206,0	(21,0)	289,4	(29,5)	348,2	(35,5)
M 18	240,3	(24,5)	284,5	(29,0)	392,4	(40,0)	475,8	(48,5)
M 20	338,4	(34,5)	402,2	(41,0)	569,0	(58,0)	676,9	(69,0)
M 22	456,2	(46,5)	539,5	(55,0)	765,2	(78,0)	912,3	(93,0)
M 24	588,6	(60,0)	696,5	(71,0)	981,0	(100,0)	1177,2	(120,0)
M 27	873,1	(89,0)	1030,0	(105,0)	1471,5	(150,0)	1765,8	(180,0)
M 30	1177,2	(120,0)	1422,4	(145,0)	1962,0	(200,0)	2354,4	(240,0)


Metrisches Feingewinde								
Abmessung	6,9		8,8		10,9		12,9	
	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)	Nm	(kpm)
M 8 x 1	22,6	(2,3)	26,5	(2,7)	37,3	(3,8)	44,1	(4,5)
M 10 x 1,25	42,2	(4,4)	51,0	(5,2)	71,6	(7,3)	86,3	(8,8)
M 12 x 1,25	78,5	(8,0)	93,2	(9,5)	132,4	(13,5)	157,0	(16,0)
M 12 x 1,5	74,5	(7,6)	88,3	(9,0)	122,6	(12,5)	147,1	(15,0)
M 14 x 1,5	122,6	(12,5)	147,1	(15,0)	206,0	(21,0)	245,2	(25,0)
M 16 x 1,5	186,4	(19,0)	220,7	(22,5)	309,0	(31,5)	372,8	(38,0)
M 18 x 1,5	296,8	(27,5)	318,8	(32,5)	451,3	(46,0)	539,5	(55,0)
M 20 x 1,5	377,7	(38,5)	451,3	(46,0)	627,8	(64,0)	755,4	(77,0)
M 22 x 1,5	510,1	(52,0)	598,4	(61,0)	843,7	(86,0)	1030,0	(105,0)
M 24 x 2	637,6	(65,0)	765,2	(78,0)	1079,1	(110,0)	1275,3	(130,0)
M 27 x 2	951,6	(97,0)	1128,1	(115,0)	1569,6	(160,0)	1912,9	(195,0)
M 30 x 2	1324,4	(135,0)	1569,6	(160,0)	2207,2	(225,0)	2648,7	(270,0)

A00519

Fig. 3.

1000499

8 History of the FENDT 900 VARIO (COM III) farm tractor



1001484

Fig. 4. FENDT 900 Vario

919 .. 0101-1000
 919 .. 1001-
 922 .. 0101-1000
 922 .. 1001-
 925 .. 0101-1000

925 .. 1001-
 928 .. 0101-1000
 928 .. 1001-
 931 .. 0101-1000
 931 .. 1001-

934 .. 0101-1000
 934 .. 1001-

T000285
 Version 4
 21-04-2009

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Chassis number	919 /.../ 0101 and up	922 /.../ 0101 and up	925 /.../ 0101 and up	928 /.../ 0101 and up	931 /.../ 0101 and up	934 /.../ 0101 and up
Technical specification extract: diesel engine						
Engine type (Deutz)	TCD 2013 L6 4V					
Engine oil (see also: fuels and lubricants in Operating Manual)	SHPD engine oil SAE 10W40					
Rotational direction	Viewed from left on flywheel					
Cylinder	6-cylinder					
Cylinder liner	Wet cylinder liner					
Piston cooling	Oil-cooled pistons (ring channel cast into piston head)					
Number of valves Inlet/outlet	2/2					
Injection process	Deutz Common Rail (DCR)					
Pressure in Common Rail (high-pressure accumulator)	approx. 400 ... approx. 1600 bar (load-dependent)					
Engine control unit (regulator)	EDC 7 (Bosch)					
Firing sequence	1 – 5 – 3 – 6 – 2 – 4 (1 cylinder on flywheel)					
Charging	Wastegate turbocharger/intercooler					
Exhaust gas recirculation with exhaust gas cooler	External exhaust gas recirculation (ext. AGR)					
Rated power to ECE R24 (KW/PS)	140/190	154/210	176/240	199/270	220/300	243/330
Maximum rated power to ECE R24 (KW/PS)	162/220	176/240	199/270	220/300	242/330	265/360
Bore/stroke (mm)	108/130					
Cubic capacity (l)	7,2					
Idle speed (rpm)	780 +/- 30					
Rated speed (rpm)	2200					
No-load speed (rpm)	2310 – 2350					
Start of delivery	Set by the EDC, load-dependent					
Valve clearance (cold engine, max. 50 °C) Inlet/outlet (°) (Note: the valve clearance is set using an X899.980.236.030 angle gauge)	75/105					
Compression ratio	18 : 1					

20

T000285

Version 4

21-04-2009

919 .. 0101-1000

919 .. 1001-

922 .. 0101-1000

922 .. 1001-

925 .. 0101-1000

925 .. 1001-

928 .. 0101-1000

931 .. 0101-1000

931 .. 1001-

934 .. 0101-1000

934 .. 1001-

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Compression pressure (bar)	20 ... 30 (Note: max. permissible deviation between cylinders is 15%)					
Min. oil pressure when warm (114°C) and in low idle speed	approx. 0.8 bar					
Cold-start system	Heater flange, additional electrical engine heater (optional)					
Fuel supply (l)	660					
Water pre-cleaner in fuel system	Standard					
Technical specification extract: transmission						
Transmission type (FENDT)	ML 260					
Transmission oil (see also: fuels and lubricants in Operating Manual)	STOU 10 W 40					
Housing coupler	Block design					
Hydrostatic units: pump/engine	233 cc / 2x 233 cc					
Forward/reverse gears	stepless/stepless					
Travel ranges	I (field)/II (road)					
Min. speed	30 m/h (0.03 km/h)					
Max. speed, travel range I (forwards)	32 km/h					
Max. speed, travel range I (reverse)	20 km/h					
Max. speed, travel range II (forwards)	60 km/h (1900 rpm) / 50 km/h (1600 rpm) / 40 km/h (1300 rpm)					
Max. speed, travel range II (reverse)	38 km/h					
Shifting	Electr. joystick					
Acceleration rate I (for special applications, e.g. road grooving machine)	0.03-0.5 km/h (1x joystick touch)					
Acceleration rate II (for field work, heavy-duty traction work)	0.5 km/h (1x joystick touch)					
Acceleration rate III (for field work, heavy-duty traction work)	1.0 km/h (1x joystick touch)					
Acceleration rate IV (for road journeys)	1,0 Km/h (1x touch of joystick)					
Emergency actuation	Mechanical adjustment of A009 actuator unit					
Towing selector (Note: observe towing instruction)	Mechanical idle setting of travel range selector					
Turbo-clutch (Y004 solenoid valve)	Electro-hydraulic					

919 .. 0101-1000
919 .. 1001-
922 .. 0101-1000
922 .. 1001-
925 .. 0101-1000

925 .. 1001-
928 .. 0101-1000
928 .. 1001-
931 .. 0101-1000
931 .. 1001-

934 .. 0101-1000
934 .. 1001-

T000285
Version 4
21-04-2009

21

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Clutch (4V5 pressure-limiting valve) Servo-assisted via Pentosin X902.011.622	Hydraulic					
Transmission oil cooler (transmission oil/air)	Standard					
Technical specification extract: rear axle						
Rear axle type (FENDT)	HA 260					
Transmission oil (see also; fuels and lubricants in Operating Manual)	STOU 10 W 40					
Rear wheel brake	Wet multiple-disc brake/pneumatically actuated					
Version: 40 km/h (18 t permissible overall weight) or 50 km/h (15 t permissible overall weight)	1-circuit brake + 4WD engagement (steering brake possible)					
Version: 40 Km/h o. 50 Km/h (18 t permissible overall weight) or 60 Km/h (16 t permissible overall weight)	2-circuit brake, 4 x individual wheel brakes (steering brake not possible)					
Parking brake ("hand brake")	Pneumatic					
Rear PTO clutch	Wet multiple-disc clutch/electro-hydraulically actuated					
Rear PTO speed	"1000" (1000 rpm)/"540E" (750 rpm) (standard) "1000" (1000 rpm)/"540" (540 rpm) (optional) or "1000" (1000 rpm)/"1000E" (1400 rpm) (optional)					
Differential lock (Rear diff. lock/front diff. lock)	Wet multiple-disc lock/electro-hydraulically actuated/ selectable under load Auto: The differential lock disengages automatically at speeds higher than 20 km/h and must be re-selected below 20 km/h The differential lock automatically disengages when the steering angle is greater than 15° and re-engages below 15° The differential lock also disengages when the foot brake is depressed and re-engages when the foot brake is released 100% diff. lock					

22

T000285

Version 4

21-04-2009

919 .. 0101-1000

919 .. 1001-

922 .. 0101-1000

922 .. 1001-

925 .. 0101-1000

925 .. 1001-

928 .. 0101-1000

928 .. 1001-

931 .. 0101-1000

931 .. 1001-

934 .. 0101-1000

934 .. 1001-

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
4WD clutch	Wet multiple-disc clutch/electro-hydraulically actuated/ selectable under load Auto: 4WD automatically disengages at speeds higher than 20 km/h and re-engages at speeds below 20 km/h 4WD is automatically disengaged when the steering angle is greater than 25°, and re-engages below 25° 100% 4WD clutch					
Axle point						
40 km/h version (18 t permissible overall weight)	Flange/stub shaft					
50 km/h version (15 t permissible overall weight)	Flange/stub shaft					
50 km/h variant (18 t permissible overall weight)	Flange/stub shaft					
60 km/h variant (16 t permissible overall weight)	Flange					
Technical specification extract: front axle						
Front axle type (FENDT)	Front axle with individual wheel suspension					
Permissible axle load	8 t					
Transmission oil (see also: fuels and lubricants in Operating Manual)	Fendt Extra Trans 10W-40					
Version with front axle brake (2-circuit brake) (wet multiple-disc brake, pneumatically actuated)	40 Km/h und 50 Km/h(18 t permissible overall weight) / 60 Km/h (16 t permissible overall weight)					
Max. permissible drive speed						
Version without front axle brake (1-circuit brake) (Note: With this version, the tractor is decelerated via the rear wheel brake and by engaging 4WD)	40 Km/h(18 t permissible overall weight) / 50 Km/h (15 t permissible overall weight)					
Max. permissible drive speed						
Front axle housing – transmission oil lubrication Variant: 2-circuit brake with/without front PTO	Forced feed lubrication Hydraulic pump: 16cc/r with 25 bar at pressure-limiting valve Drive transmission: 0.896 Hydraulic pump delivery rate: 17 l/min (at an engine speed of 1000 rpm) 35 l/min (at an engine speed of 2000 rpm)					

919 .. 0101-1000
919 .. 1001-
922 .. 0101-1000
922 .. 1001-
925 .. 0101-1000925 .. 1001-
928 .. 0101-1000
928 .. 1001-
931 .. 0101-1000
931 .. 1001-934 .. 0101-1000
934 .. 1001-T000285
Version 4
21-04-2009

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Variant: 1-circuit brake + 4WD engagement with front PTO	Forced feed lubrication Hydraulic pump: 8cc/r with 25 bar at pressure-limiting valve Drive transmission: 0.896 Hydraulic pump delivery rate: 9 l/min (at an engine speed of 1000 rpm) 18 l/min (at an engine speed of 2000 rpm)					
Variant: 1-circuit brake + 4WD engagement without front PTO	Injection lubrication					
Front axle suspension	Hydro-pneumatic individual wheel suspension with level control					
Suspension hydr. control block	Version 1: Hydr. control block without wobble stabiliser Version 2: Hydr. control block with wobble stabiliser					
Swing arm	Double suspension axle with -185/+115mm suspension travel (total 300 mm)					
Suspension characteristic	Characteristic switching (road, field hardness) and wobble support up to 60 km/h, speed-linked, brake dive and anti-squat compensation					
Technical specification extract: front PTO						
Speed (rpm)	1000					
Rotational direction	Clockwise in direction of travel					
Actuating the front PTO clutch	Electro/hydraulic (transmission oil from front axle housing)					
Front PTO clutch	Wet multiple disc clutch					
Technical specification extract: working and steering hydraulics						
Hydraulic oil (see also: fuels and lubricants in Operating Manual)	STOU 10 W 40					
Hydraulic oil cooler	Hydraulic oil/air					
Removable hydraulic oil volume	Approx. 87 l					
Hydraulic oil pre-heating at temperatures of below 0°C	Standard					
Small LS pump (PR) (axial piston pump, Rexroth A10 VO 63); drive transmission: 0.869	163 l/min (at an engine speed of 2200 rpm)/pressure: max. 200 bar					
Large LS pump (PR) (axial piston pump, Rexroth A10 VNO 85); drive transmission: 0.869	216 l/min (at an engine speed of 2200 rpm)/pressure: max. 200 bar					
Auxiliary pump (PH) (gear pump, Bosch 22.5cc/r); drive transmission: 0.896	55 l/min (at an engine speed of 2200 rpm)/pressure: max. 190 bar					

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Wheel-driven emergency pump steering (PNL) (gear pump, Bosch 8 cc/r); Drive via 4WD shaft Pumping in forwards direction Short-circuit to tank on reversing	36 l/min (at 60 km/h)/pressure: max. 190 bar 6 l/min (at 10 km/h)/pressure: max. 190 bar					
Auxiliary control valve (Bosch SB 23 LS-EHS 2)	Elec. auxiliary control valve (flow: 100 l/min, optional 140 l/min – only available in position 4)					
Response behaviour of the auxiliary control valve	Adjustable on terminal (flow rate, acceleration rate, actuation time, priority, individual locking)					
Lock valves in pressure lines of auxiliary control valve	Hydraulic servo-assistance					
Auxiliary valve emergency actuation	Hand pump for opening lock valves/main actuator opened manually					
Auxiliary control valves at rear of tractor, breakaway couplings on rear of tractor (max no. of valves, only available on Profi model)	Auxiliary control valve 1.1 "yellow" (standard) Auxiliary control valve 1.2 "blue" (standard) Auxiliary control valve 1.3 "red" (standard) Auxiliary control valve 1.4 "green" (standard) Auxiliary control valve 1.5 "brown" (optional) Auxiliary control valve 1.6 "purple" (optional)					
Auxiliary control valves in centre of tractor; breakaway couplings at front on tractor (Max. no of valves, only available on Profi model)	Auxiliary control valve 2.1 "olive" (optional) Auxiliary control valve 2.2 "grey" (optional)					
External pressure connection "Power Beyond" (PB) (optional)	Pressure: max 200 bar/flow rate: max 215 l/min (theoretical output: 71.6 KW/97 PS)					
External LS pressure increase	Can be enabled and adjusted from 0–25 bar on terminal					
EPC cut-off valve, rear power lift (Bosch)	Version 1: SA cut-off valve (single-acting) Version 2: DA cut-off valve (double-acting) (Note: field pressure can be adjusted on terminal)					
Hydraulic lower link support (optional)	The lower links can be in supported on the side by hydraulic cylinders in conjunction with the lifting height. This can also be activated manually. (Note: the hydraulic lower link support can be adjusted via the terminal)					
Maximum lifting power on the rear power lift	118 KN					
EPC cut-off valve, front power lift (Bosch)	Variant 1: SA cut-off valve (single-acting) Variant 2: DA cut-off valve (double-acting) (Note: pressure force can be adjusted on A054 terminal)					
Standard front power lift (Hydac)						
Maximum lifting power on the front power lift	55.5 KN					

919 ... 0101-1000
919 ... 1001-
922 ... 0101-1000
922 ... 1001-
925 ... 0101-1000

925 ... 1001-
928 ... 0101-1000
928 ... 1001-
931 ... 0101-1000
931 ... 1001-

934 ... 0101-1000
934 ... 1001-

T000285
Version 4
21-04-2009

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
Autoguide, control block (Danfoss)	Electr. control valve (proportional)					
Reversing driver stand	Rotary feedthrough in the cab floor					
Technical specification extract: cab						
Cab construction	5 posts					
Noise level	approx. 70 db (A)					
Air conditioning system	Automatic air conditioning with stepless fan					
Reversing driver stand	Optional					
Suspension	3-point pneumatic suspension with hydr. shock absorbers and integrated level control					
Driver seat	<p>Version 1: Fendt super deluxe seat</p> <p>Version 2: Fendt super deluxe seat, Maximo Evolution (MSG 97 AL/741)</p> <ul style="list-style-type: none"> - Active seat air conditioning for seat cooling or heating to ensure comfortable seat climate - Active weight adjustment for fully-automatic setting and adjustment of driver weight <p>Version 3: Fendt super deluxe seat, Maximo Evolution active (MSG 97 EAC/741)</p> <ul style="list-style-type: none"> - Active seat air conditioning for seat cooling or heating to ensure comfortable seat climate - Active weight adjustment for fully-automatic setting and adjustment of driver weight - Active suspension 					
Technical specification extract: electrics/electronics						

26

T000285

Version 4

21-04-2009

919 .. 0101-1000

919 .. 1001-

922 .. 0101-1000

922 .. 1001-

925 .. 0101-1000

925 .. 1001-

928 .. 0101-1000

928 .. 1001-

931 .. 0101-1000

931 .. 1001-

934 .. 0101-1000

934 .. 1001-

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
A039 multifunction armrest (MFA)	<p>Operation of:</p> <ul style="list-style-type: none"> - Vario transmission - Working hydraulics - Rear and front power lift - Rear and front PTO - 4WD and diff. lock - Front axle suspension - Tractor Management System (TMS) - Headland Management System (TI) - Automatic track guidance system (Auto-Guide) <p>There are two multifunction armrests, depending on tractor type:</p> <ul style="list-style-type: none"> - Power equipment (entry-level version) - Profi equipment (standard version) <p>Note: The Power version cannot be upgraded to the Professional version.</p>					
A007 instrument panel	<p>Displays:</p> <ul style="list-style-type: none"> - Speeds (diesel engine, rear PTO, front PTO) - Road speed (theoretical, actual (radar)) - Fill levels - Error displays - Indicator lamps 					
A036 instrument panel	<p>Operation of:</p> <ul style="list-style-type: none"> - Lighting - Rear window wiper - Automatic air conditioning - Ventilation - Central information display 					

919 .. 0101-1000
919 .. 1001-
922 .. 0101-1000
922 .. 1001-
925 .. 0101-1000

925 .. 1001-
928 .. 0101-1000
928 .. 1001-
931 .. 0101-1000
931 .. 1001-

934 0101-1000
934 1001-

Tractor type	922 Vario	924 Vario	927 Vario	930 Vario	933 Vario	936 Vario
A050 ECU, basic control unit (32-bit processor)	<p>Contents:</p> <ul style="list-style-type: none"> - Transmission - 4WD and diff. lock - Working hydraulics - Rear power lift (rear EPC) - Front power lift (standard/enhanced control) - PTO (front, rear) - Front axle suspension - Tractor Management System (TMS) - Headland management system (Teach-in "TI") - ISO bus implement control - Automatic track guidance system (Auto-Guide) 					
A038 ECU, central electrical system	<p>Contents:</p> <ul style="list-style-type: none"> - Drive light - Position light - Direction indicator - Hazard lights - Brake light - Work light - Rotating beacon - Interior lighting - Windscreen wiper (front and rear) - Rear window heater - Trailer socket - Automatic air conditioning 					
A051 ECU, engine control unit (EDC 7) (fuel-cooled)	<p>Contents:</p> <ul style="list-style-type: none"> - Engine control 					

28

T000285

Version 4

21-04-2009

919 .. 0101-1000
919 .. 1001-
922 .. 0101-1000
922 .. 1001-
925 .. 0101-1000

925 .. 1001-
928 .. 0101-1000
928 .. 1001-
931 .. 0101-1000
931 .. 1001-

934 .. 0101-1000
934 .. 1001-

9 Position of sign plates

Position of sign plates

Vehicle sign plate



right side, on front axle casing




Fig. 5.

EKI08668
 1002592

Chassis number (engraved)



right side, on front axle casing




Fig. 6.

EKI08669
 1002593

Front axle sign plate



right side, on front axle casing




Fig. 7.

EKI08670
 1002594

919 .. 0101-1000	925 .. 1001-	934 .. 0101-1000
919 .. 1001-	928 .. 0101-1000	934 .. 1001-
922 .. 0101-1000	928 .. 1001-	
922 .. 1001-	931 .. 0101-1000	
925 .. 0101-1000	931 .. 1001-	

Diesel engine sign plate



right side, on crankcase




Fig. 8.

Transmission sign plate



right side on transmission housing





Fig. 9.

Vario transmission insert sign plate



on top of Vario transmission insert



Remove cab, remove transmission cover




Fig. 10.

Rear axle sign plate



right side, on rear axle housing




Fig. 11.

Cab sign plate



in rear of cab




Fig. 12.

EKI08673

1002597

Trailer frame sign plate

NOTE: See also: *Operating manual*



right side, on trailer frame




Fig. 13.

BETR1379

1002604

Automatic trailer hitch sign plate

NOTE: See also: *Operating manual*



on trailer hitch




Fig. 14.

EKI08674

1002598

Ball-type coupling (height adjustable) sign plate

NOTE: See also: *Operating manual*



on ball-type coupling




Fig. 15.

BETR1475

1002601

Ball-type coupling sign plate

NOTE: See also: *Operating manual*



on ball-type coupling



Fig. 16.

Draw bar sign plate

NOTE: See also: *Operating manual*



on draw bar




Fig. 17.

Piton Fix sign plate

NOTE: See also: *Operating manual*



on Piton Fix




Fig. 18.

Hydraulic hitch sign plate

NOTE: See also: *Operating manual*



on hydraulic hitch




Fig. 19.

10 Tractor diagnostics with terminal

Ignition on
 Press F6.




Fig. 20.

EKI08554
 I002368

The second menu level is displayed.
 Press F6.




Fig. 21.

EKI08555
 I002369

The third menu level is displayed.
 Press F5.




Fig. 22.

EKI08556
 I002370

The diagnostics menu is displayed.
 Press F2.




Fig. 23.

EKI08557
 I002371

919 . 0101-1000	925 . 1001-	934 . 0101-1000
919 . 1001-	928 . 0101-1000	934 . 1001-
922 . 0101-1000	928 . 1001-	
922 . 1001-	931 . 0101-1000	
925 . 0101-1000	931 . 1001-	

Diagnose 1 (diagnostics 1) menu is displayed.

IDEAL	value specified by the A050 ECU, basic control unit
VE	Adjustment angle of the A009 transmission control unit
REAL	Transmission ratio actually set in the transmission

Forwards direction of travel:

IDEAL	0 to approx. 10,000 (max. value)
VE	0 to approx. 10,000 (max. value)
REAL	0 to approx. 10,000 (max. value)

Reverse direction of travel:

IDEAL	0 to approx. -10,000 (max. value)
VE	0 to approx. -10,000 (max. value)
REAL	0 to approx. -10,000 (max. value)

Scroll with **F3** key

Diagnose 2 (diagnostics 2) menu is displayed.




Fig. 24.




Fig. 25.

Legend:

- **High-pressure transmission** sensor B008, displays oil pressure in the transmission high pressure circuit
- **Getriebe -Aktion -Priorität -Funktion**, (transmission, action, priority, function) indicates the current control status of the transmission:
 1. Activation,
 2. Joystick,
 3. Quick reverse,
 4. Clutch,
 5. Speed selection,
 6. Load limit control,
 7. Final speed control,
 8. Hydrostatic pressure limiter,
 9. Engine stall protection,
 10. Engine overspeed protection,
 11. Cruise control,
 12. Emergency mode,
 13. Throttle pedal,
 14. None (default)
- **CAN1**: General CAN transmission messages in accordance with protocol 1 and 2; displayed as messages per second.
- **CAN1 status** - The CAN1 status is depicted in LED format, the LED is green when there are no faults.
- **Target speed accelerator potentiometer B055** displays target engine speed (rpm)
- **Temperature sensor discharge B009**, shows discharge temperature from the transmission high pressure circuit. Temperature values below 50°C are displayed as "**Temp. < 50°C**". Temperature values above 50°C are displayed correctly.
- **Speed target value** shows speed target value of the engine (rpm)
- **Software version** displays the software version of the terminal.

Press **F3** to return to **Diagnostics 1** menu.

NOTE: *The diagnostics terminal is no substitute for transmission pressure measurements or electrical readings; it only provides a reference value for the Vario transmission functions and the status of the CAN system.*

Possible applications:

- Tractor - loss of power
(Question: transmission or engine?).
- Transmission is overheating
(Question: how high is the transmission discharge temperature for various tasks?).
- Checking the target engine speed

