

FENDT

Werkstatthandbuch

Workshopmanual

Manuel d'atelier

Manual de taller

Manuale per l'officina

Werkplaatshandboek

FENDT 900 Vario COM III

X 990.005.057.012

1

FENDT

A	General
B	Faults
C	Documents and Diagrams
D	Component location
E	Testing
F	Setting and Calibration
G	Repair
H	Service – Info

3000

Overall system/front axle

FENDT 900 Vario - COM III

Volume 1

0000	Overall system/tractor
1005	Overall system/transmission
1010	Transmission/differential
1015	Transmission/axle drive
1050	Transmission/housing
1070	Transmission / Brake system
1080	Transmission/drive train
1200	Transmission/front PTO
1220	Transmission / Live PTO
1320	Transmission/front wheel drive
2000	Overall system/engine
2010	Engine/cylinder head
2050	Engine/cooling
2060	Engine/fuel system
2210	Engine/crankcase
2312	Engine/lubrication
2400	Engine/exhaust system
2712	Engine/injectors
3000	Overall system/front axle
3120	Front axle/steering cylinder
3180	Front axle/cardan shaft

Volume 2

4000	Overall system/steering
4090	Steering system / hydraulic steering unit
5030	Vehicle layout/operator's seat
5500	Overall system/air conditioning system
8100	Overall system/cab
8610	Power lift/EPC electro-hydraulic control
8631	Power lift/hydraulic lift
8800	Overall system/compressed air system

Volume 3

9000	Overall system/electrical system
9015	Electrical system/starter lockout

FENDT 900 Vario - COM III

Volume 4

- 9410** **Hydraulic pump installation/LS pump**
- 9430** **Hydraulic pump installation/steering pump**
- 9534** **Hydraulic piping/"Rüfa"reverse operation**
- 9600** **Overall system/hydraulic equipment**
- 9605** **Hydraulic equipment/hydraulic connections**
- 9610** **Hydraulic equipment/central control block
(ZSB)**
- 9620** **Hydraulic equipment/valve fitting**
- 9700** **Overall system/electronics**
- 9920** **Service/special tools**
- 9975** **Service/SERDIA - Deutz engine diagnostics
program**

3000 Overall system/front axle

A	General.	5
G	Repair.	21

A General

1	Front axle overview	7
2	Functional description: front axle suspension	9
3	Front axle suspension operation and function	11
4	Functional plans	12

1 Front axle overview

Front axle overview			
Vehicle type	Chassis number	FENDT spare part number	Front axle type
309 Vario COM III	336 / .. / 0101 onwards	E 339.300.020.021	Company: CARRARO Type: 20.19
310 Vario COM III	337 / .. / 0101 onwards		
311 Vario COM III	338 / .. / 0101 onwards		
312 Vario COM III	339 / .. / 0101 onwards		
411 Vario COM III	400 / .. / 0101 onwards	E 402.300.020.010	Company: DANA Type: 730/124
412 Vario COM III	401 / .. / 0101 onwards		
413 Vario COM III	402 / .. / 0101 onwards		
414 Vario COM III	403 / .. / 0101 onwards	E 404.300.020.010	Company: DANA Type: 740/152
415 Vario COM III	404 / .. / 0101 onwards		
712 Vario COM III	724 / .. / 0101 onwards	E 718.301.021.021	Company: DANA Type: 745/143
714 Vario COM III	725 / .. / 0101 onwards		
716 Vario COM III	726 / .. / 0101 onwards		
718 Vario COM III	727 / .. / 0101 onwards		
818 Vario COM III	729 / .. / 0101 onwards	E 718.301.021.021	Company: DANA Type: 745/143
820 Vario COM III	731 / .. / 0101 onwards		
820 Vario COM III "Green-tec"	731 / 27 / 0101 onwards		
922 Vario COM III "Power" (1-circuit brake)	919/21/from 0101	E 931.304.000.030	Company: DANA Type: 970/130 (40/50) km/h
924 Vario COM III "Power" (1-circuit brake)	922/21/from 0101		
927 Vario COM III "Power" (1-circuit brake)	925/21/from 0101		
930 Vario COM III "Power" (1-circuit brake)	928/21/from 0101		
933 Vario COM III "Power" (1-circuit brake)	931/21/from 0101		
936 Vario COM III "Power" (1-circuit brake)	934/21/from 0101		

Front axle overview			
Vehicle type	Chassis number	FENDT spare part number	Front axle type
922 Vario COM III "Profi" (1-circuit brake)	919/23/from 0101	E 931.303.000.030	Company: DANA Type: 970/140 (40/50/60) km/h
924 Vario COM III "Profi" (2-circuit brake)	924/23/from 0101		
927 Vario COM III "Profi" (2-circuit brake)	927/23/from 0101		
930 Vario COM III "Profi" (2-circuit brake)	930/23/from 0101		
933 Vario COM III "Profi" (2-circuit brake)	933/23/from 0101		
936 Vario COM III "Profi" (2-circuit brake)	936/23/from 0101		

2 Functional description: front axle suspension




Fig. 1.

1001321

Raise suspension

If the raise suspension button in the multifunction armrest is depressed for approx. 5 seconds, the solenoid valve (MVFH) is energised and the oil flows to the piston side of the suspension cylinders via the raise suspension non-return valve (RVFH). From the non-return valve, the oil flows straight to suspension cylinder 1 (ZF1) and via the suspension wobble stabiliser solenoid valve (MVFW) to suspension cylinder 2 (ZF2). The pressure generated in the line upstream of the raise suspension non-return valve (RVFH) causes the lower non-return valve (RVFS) to be deflected and releases the line from the piston rod side of the suspension cylinder to the tank via the pressure cut-off valve (DRVF). The pressure control valve (FRVF) is energised until a counter pressure of 100 bar is generated. The raising operation continues as long as the button is pressed.




Fig. 2.

1001322

Lower suspension

If the lower suspension button in the multifunction armrest is depressed for approx. 5 seconds, the pressure cut-off valve (DRVF) is energised and the oil flows through the lower suspension non-return valve (RVFS) at a pressure of 100 bar to the piston rod side of the suspension cylinder. The pressure generated in the line upstream of the lower suspension non-return valve (RVFS) hydraulically deflects the raise suspension non-return valve (RVFH) and releases the line from the piston side to the tank. The lowering operation continues for as long as the button is depressed.

Wobble stabiliser

Tractors with a 2-circuit brake system have a wobble stabiliser solenoid valve (MVFW) installed as standard (optional for 1-circuit brake systems). The solenoid valve is energised from a speed of 25 km/h and switches to locked mode. This severs the link between the piston ends of the two suspension cylinders and no further oil is exchanged. The lock prevents the tractor from "wobbling". Below a speed of 15 km/h, the solenoid valve is de-energised and switched to flow mode.

Lock suspension

If the lower suspension button in the multifunction armrest is briefly depressed, the lock suspension solenoid valve (MVFF) is energised and switches to locked mode. This severs the connection between the piston ends of the two suspension accumulators (ASP1 + ASP2) and the suspension cylinder, causing the suspension to become "hard", i.e. no longer damped. The suspension can only be locked at speeds below 15 km/h. At higher speeds, the valve switches back to flow and the suspension is reactivated.

3 Front axle suspension operation and function

Front axle suspension

- A Lock/lower suspension
B Lower/raise suspension

WARNING: When the tractor is stationary, raising or lowering the tractor body is dangerous for people in the vicinity of the front axle.

NOTE: Functions can only be selected while the engine is running.




Fig. 3.

BETR1682
1000974

Front axle suspension functions

- **Locked mode** (front axle suspension with harder suspension and levelling)
- **Suspension mode** (with level levelling)
- **Lower front axle suspension**
- **Raising front axle suspension**

NOTE: When the tractor is started, the function last selected is activated.

Locked mode (front axle suspension with harder suspension)

The front axle is in central position

Briefly press "Lock suspension" button (A) for less than 3 seconds.

The LED next to the button lights up.

NOTE: Locked mode automatically deactivates at speeds over 15 km/h.
The LED goes out.

Suspension mode

Briefly press "Suspension ON" button (B) for less than 3 seconds.

The LED next to the button lights up.

The front axle is in central position

NOTE: With the 2-circuit brake system, the wobble stabiliser (FSC) automatically engages over 40 km/h and automatically disengages at below 15 km/h.

FSC = Fendt Stability Control

Lower front axle suspension

Press "Lock suspension" button (A) for more than 3 seconds.

The tractor frame is lowered to the stop at the front axle.

The LED next to the button lights up.

The tractor frame will not automatically adjust to the central position of the suspension range until its speed exceeds 2 km/h.

Raising front axle suspension

When the tractor is stationary:

Press and hold "Suspension ON" button (B) for more than 3 seconds.

As long as button (B) remains pressed, the tractor frame will raise over the entire suspension range.

Only once speed exceeds 2 km/h will the tractor frame automatically adjust to the central position of the suspension range.

The LED next to the button lights up.

Levelling

Levelling is temporarily deactivated:

- during braking
- below speeds of 2 km/h
- if the front axle load is too high

4 Functional plans


Operating status: tractor suspended

Function:

- Suspension = oil exchange between cylinder and nitrogen diaphragm accumulator
- Peak pressures are limited to 250 bar with the stock valve DBVF1
- A050 - ECU, basic control unit continuously determines the mean value of all movements (B066 left wheel position sensor and B068 right wheel position sensor)
- Any deviations from the level-controlled centre position trigger the adjustment

NOTE: The front axle is only re-adjusted for speeds faster than 2 km/h.

From software version (EOL) 7.63 04/09, re-adjustment occurs at 0,5 km/h if the rear PTO is running.



EKI06903

Fig. 4.

1007357

Operating status: "raise"

Function:

- MVL charge solenoid valve activates the LS pump (PR)
- MVFH solenoid valve, raise suspension, is energised, causing the RVFS lower suspension non-return valve to be opened and oil to be fed to the piston crown side (compression stage)
- Suspension pressure cut-off valve (DRVF) is energised with approx. half voltage, hence generating approx. 100 bar of pressure on the piston rod side (drawing stage).
- The flow through cover 1.8 mm determines the lift speed




Fig. 5.

EKI06904
1007358

Operating status: "lower"

Function:

- MVL charge solenoid valve activates the LS pump (PR)
- The suspension pressure cut-off valve is energised with approx. half voltage, causing the suspension non-return valve to be opened hydraulically and oil to be fed to the piston rod side (retraction stage) up to approx. 100 bar
- The flow through cover 1.8 mm determines the lowering speed




Fig. 6.

EKI06905
1007359

Operating status: "locking the suspension"

Function:

- Lock suspension solenoid valve (MVFF) is energised; oil flow to the hydraulic accumulators is stopped
- The suspension can only be locked below 20 km/h. If the vehicle exceeds this speed, the MVFF lock suspension solenoid valve is no longer energised by the A050 ECU, basic control unit.
- If the vehicle slows to below this speed, the "locking the suspension" function is **not** reactivated automatically.




Fig. 7.

EKI06907

1007361

"Tractors without wobble stabiliser"

- The suspension wobble stabiliser solenoid valve MVFW is not installed **as standard** in tractors with a 1-circuit brake system.




Fig. 8.

EK106908
1007362

NOTE: Vehicles with chassis numbers **9XX/21/1701** and higher can be retrofitted with this equipment **upon request**.

Operating status: "wobble stabiliser"

Function:

16

T002576
Version 3
05-10-2009

919 .. 0101-1000
919 .. 1001-
922 .. 0101-1000
922 .. 1001-
925 .. 0101-1000

925 .. 1001-
928 .. 0101-1000
928 .. 1001-
931 .. 0101-1000
931 .. 1001-

934 .. 0101-1000
934 .. 1001-

- MVFW suspension wobble stabiliser solenoid valve is energised when certain conditions are met:
- The tractor is driving faster than 20 km/h.
- Rotary position sensors B066, left wheel position sensor and B068 right wheel position sensor are in the same position. This means that the tractor is level, maximum permissible tolerance 25 mm.
- Energising the MVFW suspension wobble stabiliser solenoid valve causes oil to flow between right and left, the axle is prevented from swinging and, as a result, the tractor is more stable when negotiating bends.
- However, there is still some resilience in the axle: the ZF1 left suspension cylinder springs back into ASP1 suspension accumulator 1 and the ZF2 right suspension cylinder springs back into ASP2 suspension accumulator 2
- At speeds below 15 km/h with **no** brakes applied, the wobble stabiliser is switched off.
- While the wobble stabiliser is active, the front axle is **not** readjusted (raising or lowering).




Fig. 9.

EKI06906

1007360

Wobble stabiliser diagnostics




Fig. 10.

1010491

The activation conditions depend on the **EOL** software version.

The best way to control the activation condition is via the Vario diagnostics (arrow).

Operating status: "suspension blocked" = "suspension OFF"

Function:

- There is always some hydraulic pressure in the suspension cylinders at the pressure stage (load) and retraction stage
- This pressure cannot be released either by pressing a button or switching off the engine
- When repair work is undertaken between the front axle suspension and the central control block, this pressure must always be released.



WARNING: Chassis may lower

This is achieved by opening the suspension 1 lock valve

- and the suspension 2 lock valve in order to release the pressure to the tank.
- See also "Safety briefing" - Chapter 0000 Reg. A




Fig. 11.

EKI06903

1007357


G Repair

1	Removing front axle	23
2	Fitting front axle	26

1 Removing front axle

Preliminary work:

- Remove cooler assembly see 53



Disconnect all cable connectors in the area of the front axle and attach them to the engine





Fig. 1.

1003201



Relieve pressure on the front axle suspension accumulator (open both suspension lock valves)





Fig. 2.

1003206



Remove hydraulic lines (arrows) on the left side





Fig. 3.

1003203



Remove front axle suspension diaphragm accumulator





Fig. 4.

I003207



Remove hydraulic lines (arrows) on the right side (may vary according to equipment)





Fig. 5.

I003204



Remove hydraulic lines of the auxiliary control valves in the middle (arrows) (may vary according to equipment)





Fig. 6.

I003205



Remove hydraulic lines from the front cover (may vary according to equipment)





Fig. 7.

I003419



Remove filter for front axle (if present) together with hydraulic line





Fig. 8.

I003208



Remove front axle suction line (if present)





Fig. 9.

I003210



Place assembly trestle under engine, carefully lift the front axle and remove the connecting bolts between the engine and the front axle





Fig. 10.

I003214



Remove front axle

NOTE: Ensure there is sufficient clearance between all components.

! **DANGER: Do not walk or stand under suspended loads!**





Fig. 11.

I004194

2 Fitting front axle



Carefully lift and fit the front axle

NOTE: Ensure there is sufficient clearance between all components.




DANGER: Do not walk or stand under suspended loads!



Fig. 12.

I004194



Tighten flange screws

Tightening torque: 580 Nm





Fig. 13.

I003221



Install the suspension diaphragm accumulator and connect hydraulic lines





Fig. 14.

I003222



When replacing the front axle: Remove plug for brake line





Fig. 15.

I003223



When replacing the front axle: Fit screw sockets for brake line





Fig. 16.

1003224



When replacing the front axle: Install brake line from the front





Fig. 17.

1003225




Connect brake line on the left and right



Fig. 18.

1003226



Connect brake line





Fig. 19.

1003249

919 .. 0101-1000
 919 .. 1001-
 922 .. 0101-1000
 922 .. 1001-
 925 .. 0101-1000

925 .. 1001-
 928 .. 0101-1000
 928 .. 1001-
 931 .. 0101-1000
 931 .. 1001-

934 .. 0101-1000
 934 .. 1001-



When replacing the front axle: Fit screw sockets for steering hydraulic system





Fig. 20.

1003251



Install line for the steering hydraulic system




Fig. 21.

1003248



When replacing the front axle: Install diaphragm accumulator for the front hydraulic system





Fig. 22.

1003250



If present: Install bracket for the front power lift hydraulic line





Fig. 23.

1003252



When replacing the front axle: Fit screw sockets





Fig. 24.

1003253



When replacing the front axle: Fit screw sockets for the lubrication line





Fig. 25.

1003254



Fit suction line





Fig. 26.

1003210



Fit pressure line with filter





Fig. 27.

1003208

919 .. 0101-1000
 919 .. 1001-
 922 .. 0101-1000
 922 .. 1001-
 925 .. 0101-1000

925 .. 1001-
 928 .. 0101-1000
 928 .. 1001-
 931 .. 0101-1000
 931 .. 1001-

934 .. 0101-1000
 934 .. 1001-



Tighten all hydraulic lines that were loosened on the left side





Fig. 28.

1003203



Tighten all hydraulic lines that were loosened on the right side





Fig. 29.

1003204



Tighten all hydraulic lines that were loosened on the central control block





Fig. 30.

1003205



Tighten all hydraulic lines that were loosened on the front cover





Fig. 31.

1003419



Screw in and lock the suspension stop valves




Fig. 32.

1003206

Final procedures:

- Fitting cooler assembly see §4

